


MATERIALS

BODY	BRASS NICKEL PLATED
CONTACT	GOLD PLATED
INSULATOR	PTFE
FERRULE	GOLD PLATED




MOUNTING HOLE





ASSEMBLY PROCEDURES

- 1. STRIP CABLE AS SHOWN. DO NOT NICK CENTER CONDUCTOR. TIN CENTER CONDUCTOR.
- 2. SLIDE FERRULE (1) & CXMP NUT (2) OVER CABLE. FLAR BRAID & SLIDE WEDGE ASSEMBLY (3) UNDER BRAID WITH CENTER CONDUCTOR PROTRUDING THROUGH HOLE IN INSULATOR. SLIDE FERRULE (1) OVER BRAID & AGAINST EXTENSION. SOLDER FERRULE (1) TO BRAID THROUGH HOLE IN FERRULE.



3. SOLDER CONTACT TO CENTER
CONDUCTOR. CLEAN. INSERT CABLE
ASSEMBLY INTO BODY & TIGHTEN.



8th Floor, Building 1, Yongfu Science and Technology Center Industrial Park, Nanzha District 5, Humen,523900, Dongguan, Guangdong, China.

Website: www.ebeestock.com
Email: sales@ebeestock.com

COAXIAL & FIBER OPTICS

DWG TITLE ET11259	DES_ : sma-female-bulkhead-connector-solder-connector-solder-connector-solder-solder-connector-solder-solder-connector-solder-connector-solder-solder-connector-solder-solder-connector-solder-connector-solder-solder-connector-so	·
SIZE A FSCM NO. 53919 CAD FILE 073102 SCALE N/A 127		

NOTES:

- 1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE NOMINAL.
- 2. ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.